

Tire Maintenance Guide for Nigerian Roads

Here's a guide to maintaining your tires in Nigeria:

- 1. Check tire pressure regularly:** Keep your tires inflated to the manufacturer's recommended pressure to avoid blowouts and improve fuel efficiency.
- 2. Inspect for wear and tear:** Nigerian roads can cause uneven tire wear, so check your tires for cracks, cuts, or bald spots. Replace tires showing significant damage.
- 3. Rotate tires every 5,000 to 10,000 km:** Rotating tires evenly distributes wear, especially when dealing with uneven surfaces.
- 4. Balance and align your wheels:** Regular alignment helps prevent uneven wear, especially after hitting potholes, a common issue on Nigerian roads.
- 5. Use high-quality tires:** Invest in durable tires made for tough conditions. Reinforced sidewalls help protect against sharp objects.